Test ID	Test Description	Expected Outcome	Actual Result		
	LOGIN + PA	SSWORD CHANGE	•		
1	Log-in with correct username and password - username: test@gmail.com - password: testtest	Successful login	Successful login		Key:
2	Log-in with incorrect username and correct password - username: wrong-test@gmail.com - password: testtest	Unsuccessful login	Unsuccessful login	Correct resul	t
3	Log-in with correct username and incorrect password - username: test@gmail.com - password: wrongwrong	Unsuccessful login	Unsuccessful login	Incorrect resu	It
4	After Password Change, log-in with correct username and new password - username: test@gmail.com - (new) password: updatedupdated	Successful login	Successful login	Unclear resul	t
5	After Password, Change, log-in with correct username and old password - username: test@gmail.com - (old) password: testtest	Unsuccessful login	Unsuccessful login		
	CRE	ATE HABIT	•		
	Prerequisites 1. Login as TestUser - Username: test@gmail.com - Password: testtest	Teardown 1. Delete any created Habits		Benchmark	80% Code Coverage
6	Create Habit (Text) 1. Click + button on Habit page 2. Fill and select the following fields - Name: Test - Frequency: Daily - Privacy: Private - Activity: - Label: TestActivity - Type: Text 3. Click submit button	New habit is added to the Habit List with the name Test Viewing habit matches the details provided.	Pass	Instructions	1. Run Prerequisites 2. Run all Test Cases 3. Run Teardown
7	Create Habit (Numerical)  1. Click + button on Habit page  2. Fill and select the following fields  - Name: Test  - Frequency: Daily  - Privacy: Private  - Activity:  - Label: TestActivity  - Type: Numerical  3. Click submit button	New habit is added to the Habit List with the name Test Viewing habit matches the details provided.	Pass		

8	Create Habit (Scale) 1. Click + button on Habit page 2. Fill and select the following fields - Name: Test - Frequency: Daily - Privacy: Private - Activity: - Label: TestActivity - Type: Scale - Upper Bound: 10 - Lower Bound: 1 - Interval: 2 3. Click submit button	New habit is added to the Habit List with the name Test Viewing habit matches the details provided.	Pass	
9	Create Habit (Checkmark)  1. Click + button on Habit page  2. Fill and select the following fields  - Name: Test  - Frequency: Daily  - Privacy: Private  - Activity:  - Label: TestActivity  - Type: Checkmark  3. Click submit button	New habit is added to the Habit List with the name Test Viewing habit matches the details provided.	Pass	
10	Multiple Activities  1. Click + button on Habit page  2. Fill and select the following fields  - Name: Test  - Frequency: Daily  - Privacy: Private  - Activity1:  - Label: TestActivity1  - Type: Text  - Activity2:  - Label: TestActivity2  - Type: Numerical  - Activity3:  - Label: TestActivity3  - Type: Scale  - Upper Bound: High  - Lower Bound: Low  - Interval: 2  - Activity4:  - Label: TestActivity4  - Type: Checkmark  3. Click submit button	New habit is added to the Habit List with the name Test Viewing habit matches the details provided.	Pass	
11	Unsuccessful Create (empty Name) 1. Click + button on Habit page 2. Fill and select the following fields - Name: (blank) - Frequency: Daily - Privacy: Private - Activity: - Label: TestActivity - Type: Text 3. Click submit button	Warning message displayed at the top of the Create page. Name field is highlighted in red	Pass	

12	Unsuccessful Create (empty Label) 1. Click + button on Habit page 2. Fill and select the following fields - Name: Test - Frequency: Daily - Privacy: Private - Activity: - Label: (blank) - Type: Text 3. Click submit button	Warning message displayed at the top of the Create page. Label field is highlighted in red	Pass	
13	Unsuccessful Create (empty Upper Bound)  1. Click + button on Habit page  2. Fill and select the following fields  - Name: Test  - Frequency: Daily  - Privacy: Private  - Activity:  - Label: TestActivity  - Type: Scale  - Upper Bound: (blank)  - Lower Bound: Low  - Interval: 2  3. Click submit button	Warning message displayed at the top of the Create page. Upper Bound field is highlighted in red	Pass	
14	Unsuccessful Create (empty Lower Bound)  1. Click + button on Habit page  2. Fill and select the following fields  - Name: Test  - Frequency: Daily  - Privacy: Private  - Activity:  - Label: TestActivity  - Type: Scale  - Upper Bound: High  - Lower Bound: (blank)  - Interval: 2  3. Click submit button	Warning message displayed at the top of the Create page. Lower Bound field is highlighted in red	Pass	
15	Unsuccessful Create (Interval < 2) 1. Click + button on Habit page 2. Fill and select the following fields - Name: Test - Frequency: Daily - Privacy: Private - Activity: - Label: TestActivity - Type: Scale - Upper Bound: High - Lower Bound: Low - Interval: 1 3. Click submit button	Warning message displayed at the top of the Create page. Interval field is highlighted in red	Pass	

16	Unsuccessful Create (empty Upper Bound, empty Lower Bound & Interval < 2) 1. Click + button on Habit page 2. Fill and select the following fields - Name: Test - Frequency: Daily - Privacy: Private - Activity: - Label: TestActivity - Type: Scale - Upper Bound: (blank) - Lower Bound: (blank) - Interval: 1 3. Click submit button	Warning message displayed at the top of the Create page. Upper Bound field, Lower Bound field and Interval field are highlighted in red	Pass	
17	Unsuccessful Create (Remove last Grouping) 1. Click + button on Habit page 2. Fill and select teh following fields - Name: Test - Frequency: Daily - Privacy: Private 3. Click the - button on Activity1	A warning pops up telling user that a Habit requires a minimum of one Grouping	Pass	
18	Unsuccessful Create (Create 20+ Grouping) 1. Click + button on Habit page 2. Fill and select teh following fields - Name: Test - Frequency: Daily - Privacy: Private 3. Click the + button on at the bottom of the Create page (Repeat 19x)	A warning pops up telling user that a Habit has a maximum of 20 Groupings	Pass	
	E	DIT HABIT		
	Prerequisites  1. Login as TestUser			
19	Edit Habit (Name) 1. Select Test Habit 2. Click Edit button 3. Change the Following Field - Name: NewTest 4. Click Save button	Habit has been renamed to "NewTest" in both the habit viewer and in the habit list	Pass	
20	Edit Habit (Frequency) 1. Select Test Habit 2. Click Edit button 3. Change the Following Field - Frequency: Weekly 4. Click Save button	Habit Frequency now reads "Weekly"	Pass	

21	Edit Habit (Privacy)  1. Select Test Habit  2. Click Edit button  3. Change the Following Field  - Privacy: Public  4. Click Save button	Habit Privacy now reads "Public"	Pass	
22	Edit Habit (Label)  1. Select Test Habit  2. Click Edit button  3. Change the Following Field  - Activity:  - Label: NewTestActivity  4. Click Save button	Grouping label now reads "NewTestActivity"	Pass	
23	Edit Habit (Type - Numerical)  1. Select Test Habit  2. Click Edit button  3. Change the Following Field  - Activity:  - Type: Numerical  4. Click Save button	Input field for Grouping is now a number field	Pass	
24	Edit Habit (Type - Scale)  1. Select Test Habit  2. Click Edit button  3. Change the Following Field  - Activity:  - Type: Scale  - Upper Bound: 10  - Lower Bound: 1  - Intervan: 2  4. Click Save button	Input field for Grouping is now a scale with the left side labeled as the Low, the right side labeled as High and with there being two positions, the left and the right	Pass	
25	Edit Habit (Type - Checkmark)  1. Select Test Habit  2. Click Edit button  3. Change the Following Field  - Activity:  - Type: Checkmark  4. Click Save button	Input field for Grouping is now a checkmark	Pass	
26	Edit Habit (Type - Text)  1. Select Test Habit  2. Click Edit button  3. Change the Following Field  - Activity:  - Type: Text  4. Click Save button	Input field for Grouping is now a text area	Pass	
27	Edit Habit (Add Activity)  1. Select Test Habit  2. Click Edit button  3. Click the + button at the bottom of the Edit page  3. Fill in and select the Following Field  - Activity2:  - Label: TestActivity2  - Type: Text  4. Click Save button	Second Grouping has been added to Habit	Pass	

28	Edit Habit (Remove Grouping - Must have 2 Groups)  1. Select Test Habit  2. Click Edit button  3. Click the - button at the bottom of Activity2  4. Click Save button	Second Grouping has been removed from Habit	Pass	
29	Unsuccessful Edit (Empty Field - Name)  1. Select Test Habit  2. Click Edit button  3. Change the Following Field - Name: (blank)  4. Click Save button	Top of the Edit page gives a warning that required field is not filled in, highlighted in red Name field is highlighted in red	Pass	
30	Unsuccessful Edit (Empty Field - Label)  1. Select Test Habit  2. Click Edit button  3. Change the Following Field  - Activity:  - Label: (blank)  4. Click Save button	Top of the Edit page gives a warning that required field is not filled in, highlighted in red Label field is highlighted in red	Pass	
31	Unsuccessful Edit (Empty Field - Upper Bound)  1. Select Test Habit  2. Click Edit button  3. Change the Following Field  - Activity:  - Type: Scale  - Upper Bound: (blank)  - Lower Bound: Low  - Interval: 2  4. Click Save button	Top of the Edit page gives a warning that required field is not filled in, highlighted in red Upper Bound field is highlighted in red	Pass	
32	Unsuccessful Edit (Empty Field - Lower Bound)  1. Select Test Habit  2. Click Edit button  3. Change the Following Field  - Activity:  - Lower Bound: (blank)  4. Click Save button	Top of the Edit page gives a warning that required field is not filled in, highlighted in red Lower Bound field is highlighted in red	Pass	
33	Unsuccessful Edit (Incorrect Field - Interval)  1. Select Test Habit  2. Click Edit button  3. Change the Following Field  - Activity:  - Interval: 1  4. Click Save button	Top of the Edit page gives a warning that required field is not filled in, highlighted in red Interval field is highlighted in red	Pass	
34	Unsuccessful Edit (Remove Last Grouping)  1. Select Test Habit  2. Click Edit button  3. Click the - button at the bottom of Activity	Warning pop up saying that a Habit requires at least one Grouping	Pass	
35	Unsuccessful Edit (Create 20+ Groupings) 1. Select Test Habit 2. Click Edit button 3. Click the + button at the bottom of Activity (Repeat 19x)	Warning pop up saying that a Habit can have a max of 20 Groupings	Pass	
36	Delete Habit (Stopped)  1. Select Test Habit  2. Click Edit button  3. Click Delete button at the bottom of the Edit page  4. Click Cancel	Habit remains unchanged	Pass	

37	Delete Habit (Confirmed)  1. Select Test Habit  2. Click Edit button  3. Click Delete button at the bottom of the Edit page  4. Click Ok	Habit is removed from Habit list Habit is no longer viewable	Pass	
	VIEV	VING HABITS		
	Prerequisites  1. Login as TestUser02	Teardown: 1. Delete Test02 Habit 1.1 Select Test02 Habit 1.2 Click Edit button 1.3 Click Delete button 1.4 Click Ok		
38	Submit Habit (Successful)  1. Select Habit Test02  2. Enter values: - Activity1 => Text test - Activity2 => 1.0 - Activity3 => 5th interval - Activity4 => Checked  3. Click submit button	Activity1: Table expanded with current date & "Text test" Activity2: Line Graph should have one value => 1.0 Activity3: Line Graph should have one value => 5 Activity4: Line Graph should have one value => 1 Submit button should be grayed out	Pass	
39	Resubmit Habit (Unsuccessful) 1. Select Habit Test02 2. Click the submit button	Submit button should not be clickable	Pass	
40	Cycle Through Timeframes (Line Graph) 1. Select Habit Test01 2. Navigate to Activity3 3. Select "Weekly" for Activity3 Visualization 4. Select "Monthly" for Activity3 Visualization 5. Select "Daily" for Activity3 Visualization	3. Visualization should shift with x-axis formatted as "Year-Month-First Day of the Week/Last Day of the Week" with three values 1, 3 and 5.  4. Visualization should shift with x-axis formatted as "Year-Month" with three values 1, 3, and 5  5. Visualization should shift to original graph	Pass	

41	Cycle Through Timeframes (Bar Graph) 1. Select Habit Test01 2. Navigate to Activity3 3. Select "Bar" for Activity3 Visualization 4. Select "Weekly" for Activity3 Visualization 5. Select "Monthly" for Activity3 Visualization 6. Select "Daily" for Activity3 Visualization	3. Visualization should switch from a single point visualization to a single Bar visualization 4. Visualization should shift with x-axis formatted as "Year-Month-First Day of the Week/Last Day of the Week" with three values 1, 3 and 5. 5. Visualization should shift with x-axis formatted as "Year-Month" with three values 1, 3, and 5 6. Visualization should shift to original Bar graph	Pass	
42	Cycle Through Timeframes (Pie Graph)  1. Select Habit Test01  2. Navigate to Activity3  3. Select "Pie" for Activity3 Visualization  4. Select "Weekly" for Activity3 Visualization  5. Select "Monthly" for Activity3 Visualization  6. Select "Daily" for Activity3 Visualization	3. Visualization should switch from a single point visualization to a single value Pie visualization 4. Visualization should shift with labels formatted as "Year-Month-First Day of the Week/Last Day of the Week" with three values 1, 3, and 5. 5. Visualization should shift with labels formatted as "Year-Month" with three values 1, 3, and 5. 6. Visualization should shift to original Pie graph	Pass	
43	2. Navigate to Activity2 3. Select "Highest" for Activity3 Statistic	Statistic should display a value of 5     Statistic should display a value of 1     Statistic should display a value of 3     Statistic should display a value of 3	Pass	
		PROFILE		
	Prerequisites:  1. Login as TestUser  - Username: test@gmail.com  - Password: testtest			
44	Select "Weekly" option     Select "Monthly" option     Select "Daily" option	User's Notification Frequency changes to Weekly     User's Notification Frequency changes to Monthly     User's Notification Frequency changes to Daily (initial value)	Pass	
45	Signout: 1. Click the Sign Out button	1. Return to the Login/Registration page	Pass	
		RIENDS		

	Prerequisites:  1. Login as TestUser  - Username: test@gmail.com  - Password: @testtest  2. Create Habit Test03  2.1 Navigate to Habit page  2.2 Click + button  2.3 Fill and select the following fields  - Name: Test03  - Frequency: Daily  - Privacy: Public  - Activity1  - Label: Activity1  - Type: Text  2.4 Click the submit button	Teardown: 1. Delete Test03 Habit 1.1 Select Test03 Habit 1.2 Click Edit button 1.3 Click Delete button 1.4 Click Ok		
46	Send Friend Request 1. Input into the Search bar: test02@gmail.com 2. Click on the "Add" button 3. Logout 4. Login with TestUser02 - Username: test02@gmail.com - Password: testtest02 5. Navigate to Friends page	TestUser has a pending friend named "test02@gmail"     TestUser02 has a Invite with the name "test@gmail.com"	Pass	
47	Accept Friend Request 1. Click on the "Accept" button as TestUser02 2. Logout of TestUser02 3. Login to TestUser - Username: test@gmail.com - Password: testtest 4. Navigate to "Friends" page	TestUser02 has no invites left     TestUser02 has a friend named     "test@gmail.com"     TestUser has a friend named     "test02@gmail.com"	Pass	
48	React to Post  1. Complete Habit Test03  1.1 Select Test03 Habit  1.2 Fill in the following field  - Activity1: Testing  1.3 Click the submit button  2. Navigate to Friends page  3. React to Post of Test03  - Click "Thumbs Up" reaction on Post of Test03  4. Logout of TestUser  5. Login as TestUser02  - Username: test02@gmail.com  - Password: testtest02  6. Navigate to Friends page  7. Click on Reactions List for Post of Test03  8. React to Post of Test03  - Click "Heart" reaction on Post of Test03  9. Logout of TestUser02  10. Login as TestUser  - Username: test@gmail.com  - Pasword: testtest  11. Navigate to Friends page  12. Click on Reactions List	6. TestUser02 sees one Reaction (Thumbs Up) 8. TestUser02 sees two Reactions (Thumbs Up, Heart) 12. TestUser sees two Reactions (Thumbs Up, Heart)	Pass	

49	Remove Friend 1. Click on the "Remove" button next to "testuser02@gmail.com" 2. Logout of TestUser 3. Login as TestUser0 - Username: test02@gmail.com - Password: @testuser02!Password 4. Navigate to Friends page	TestUser has no friends     TestUser02 has no friends	Pass	
50	Reject Friend Request 1. Input into the Search bar: test@gmail.com 2. Click on the "Add" button 3. Logout 4. Login with TestUser - Username: test@gmail.com - Password: testtest 5. Navigate to "Friends" page 6. Click the Remove button 7. Login with TestUser02 - Username: test02@gmail.com - Password: @testuser02!Password 8. Navigate to the Friends page	6. TestUser has no remaining Invites 6. TestUser has no friends 8. TestUser02 has no friends	Pass	